



0.75KW~300KW 220V/440V Class

Flux Vector Control Inverter

# ERIC-9001 Series

INSTRUCTION  
MANUAL



No.18791

**RICH**  
ELECTRIC

---

## PREFACE

ERIC-9001 inverter provided with vector control for standard models in addition to V/f control. This instruction manual describes installation, maintenance and inspection, troubleshooting, and specifications of the ERIC-9001. Read this instruction manual thoroughly before operation.

RICH ELECTRIC CO., LTD.

### General Precautions

- Some drawings in this manual are shown with the protective cover or shields removed, in order to describe detail with more clarity. Make sure all covers and shields are replaced before operating this product.
- This manual may be modified when necessary because of improvement of the product, modification, or changes in specifications. Such modifications are denoted by a revised manual No.
- To order a copy of this manual, if your copy has been damaged or lost, contact your RICH ELECTRIC representative.
- RICH ELECTRIC is not responsible for any modification of the product made by the user, since that will void your guarantee.

---

## NOTES FOR SAFE OPERATION

Read this instruction manual thoroughly before installation, operation, maintenance or inspection of the ERIC-9001. In this manual, NOTES FOR SAFE OPERATION are classified as "WARNING" or "CAUTION".


 **WARNING**


Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury to personnel.

 **CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury to personnel and damage to equipment.

It may also be used to alert against unsafe practices.

Even items described in  **CAUTION** may result in a vital accident in some situations. In either case, follow these important notes.

 **NOTE** : These are steps to be taken to insure proper operation.

### RECEIVING

 **CAUTION**

- Do not install or operate any inverter which is damaged or has missing parts.  
Failure to observe this caution may result in personal injury or equipment damage.

## INSTALLATION

### CAUTION

- Lift the cabinet by the base. When moving the unit, never lift by the front cover.  
Otherwise, the main unit may be dropped causing damage to the unit.
- Mount the inverter on nonflammable material (i.e. metal).  
Failure to observe this caution can result in a fire.
- When mounting units in an enclosure, install a fan or other cooling device to keep the intake air temperature below 45°C.  
Overheating may cause a fire or damage to the unit.

## WIRING

### WARNING

- Only commence wiring after verifying that the power supply is turned OFF.  
Failure to observe this warning can result in an electrical shock or a fire.
- Wiring should be performed only by qualified personnel.  
Failure to observe this warning can result in an electrical shock or a fire.
- When wiring the emergency stop circuit, check the wiring thoroughly before operation.  
Failure to observe this warning can result in personal injury.

- 
- Make sure to ground the ground terminal ⊕.  
(Ground resistance  
220V class: 100Ω or less, 440V class: 10Ω or less)  
Failure to observe this warning can result in an electrical shock  
or a fire.

 **CAUTION**

- Verify that the inverter rated voltage coincides with the  
AC power supply voltage.  
Failure to observe this caution can result in personal injury  
or a fire.
- Do not perform a withstand voltage test of the inverter.  
It may cause semi-conductor elements to be damaged.
- To connect a braking resistor, braking resistor unit or  
braking unit, follow the procedures described in  
APPENDIX 3.  
Improper connection may cause a fire.
- Tighten terminal screws to the specified tightening  
torque.  
Failure to observe this caution can result in a fire.
- Never connect the AC main circuit power supply to  
output terminals U, V and W.  
The inverter will be damaged and invalidate the guarantee.

## OPERATION

### WARNING

- Only turn ON the input power supply after replacing the front cover. Do not remove the cover while current is flowing.  
Failure to observe this warning can result in an electrical shock.
- When the retry function (L5-02) is selected, do not approach the inverter or the load, since it may restart suddenly after being stopped.  
(Construct machine system, so as to assure safety for personnel, even if the inverter should restart.) Failure to observe this warning can result in personal injury.
- Since the stop button can be disabled by a function setting, install a separate emergency stop switch.  
Failure to observe this warning can result in personal injury.
- If an alarm is reset with the operation signal ON, the inverter restarts automatically. Only reset the alarm after verifying that the operation signal is OFF.  
Failure to observe this warning can result in personal injury.

### CAUTION

- Never touch the heatsink or discharging resistor since the temperature is very high.  
Failure to observe this caution can result in harmful burns to the body.
- Since it is easy to change operation speed from low to high speed, verify the safe working range of the motor and machine before operation.  
Failure to observe this caution can result in personal injury and machine damage.

- 
- Install a holding brake separately if necessary.  
Failure to observe this caution can result in personal injury.
  - Do not change signals during operation.  
The machine or the inverter may be damaged.
  - All the constants of the inverter have been preset at the factory. Do not change the settings unnecessarily.  
The inverter may be damaged. For supply voltage, follow Par. 4.3.

## MAINTENANCE AND INSPECTION

### WARNING

(Ref. page)

- Never touch high-voltage terminals in the inverter.  
Failure to observe this warning can result in an electrical shock.
- Replace all protective covers before powering up the inverter. To remove the cover, make sure to shut OFF the molded-case circuit breaker.  
Failure to observe this warning can result in an electrical shock.
- Perform maintenance or inspection only after verifying that the CHARGE LED goes OFF, after the main circuit power supply is turned OFF.  
The capacitors are still charged and can be dangerous.
- Only authorized personnel should be permitted to perform maintenance, inspections or parts replacement.  
[Remove all metal objects (watches, bracelets, etc.) before operation.]  
(Use tools which are insulated against electrical shock.)  
Failure to observe this warning can result in an electrical shock.

 **CAUTION**

- The control PC board employs CMOS ICs. Do not touch the CMOS elements.  
They are easily damaged by static electricity.
- Do not connect or disconnect wires or connectors while power is applied to the circuit.  
Failure to observe this caution can result in personal injury.

**Others**

 **WARNING**

- Never modify the product.  
Failure to observe this warning can result in an electrical shock or personal injury and will invalidate the guarantee.



---

# CONTENTS

NOTES FOR SAFE OPERATION.....	2
1 RECEIVING.....	9
1.1 INSPECTION CHECKPOINTS.....	9
2 INSTALLATION.....	11
2.1 CHOOSING A LOCATION TO MOUNT THE INVERTER.....	12
2.2 CLEARANCES.....	13
3 WIRING.....	14
3.1 CONNECTION DIAGRAM.....	15
3.2 WIRING THE MAIN CIRCUIT.....	17
3.3 WIRING THE CONTROL CIRCUIT.....	21
3.4 WIRING INSPECTION.....	22
4 OPERATION.....	23
4.1 OPERATION MODE SELECTION.....	24
4.2 TEST RUN CHECKPOINTS.....	25
4.3 TEST RUN.....	26
5 SETTING OPERATION CONDITIONS.....	32
5.1 DIGITAL OPERATOR KEY DESCRIPTION.....	32
5.2 DIGITAL OPERATOR MODE SELECTION.....	33
5.3 OPERATION MODE.....	34
5.4 INITIALIZE MODE.....	38
5.5 PROGRAMMING MODE.....	40
5.6 MODIFIED CONSTANTS MODE.....	44
6 MAINTENANCE AND INSPECTION.....	45
6.1 PERIODIC INSPECTION.....	46
6.2 PARTS REPLACEMENT SCHEDULE(GUIDELINES).....	47
7 TROUBLESHOOTING.....	48
7.1 FAULT DIAGNOSIS AND CORRECTIVE ACTIONS.....	48
7.2 MOTOR FAULTS AND CORRECTIVE ACTIONS.....	53
APPENDIX 1 SPECIFICATIONS.....	54,55
APPENDIX 2 DIMENSIONS (mm).....	56
APPENDIX 3 TYPICAL CONNECTION DIAGRAM.....	57
3.1 BRAKING UNIT AND BRAKING RESISTOR UNIT.....	57
3.2 WITH TRANSISTOR OPEN COLLECTOR FOR OPERATION SIGNAL.....	58
3.3 WITH CONTACT OUTPUT, OPEN COLLECTOR OUTPUT.....	59
APPENDIX 4 CONSTANTS LIST.....	60

# 1 RECEIVING

## ⚠ CAUTION

- Do not install or operate any inverter which is damaged or has missing parts.  
Failure to observe this caution may result in personal injury or equipment damage.

This chapter describes how to verify the inverter after delivery to the user.

## 1.1 INSPECTION CHECKPOINTS

### (1) Receiving Checkpoints

Table 1 Checkpoints

Checkpoints	Description
Does the inverter model number correspond with the purchase order?	Check the model number on the nameplate on the side of the ERIC-9001
Are any parts damaged?	Visually check the exterior and verify that there was no damage during transport.
Is hardware properly seated and securely tightened?	Remove inverter front cover. Check all visible hardware with appropriate tools.
Was an instruction manual received?	ERIC-9001 instruction manual. : TOE-S616-10.10)

If any of the above checkpoints are not satisfactory, contact your RICH ELECTRIC representative.

### (2) Checking the Nameplate Data

#### (a) Nameplate Data

An example for Types of 3-phase, 220V AC 1HP

(0.75kw)

TRANSISTORIZED INVERTER	
MODEL	: EI-01L
SOURCE	: AC200V~230V
CAPACITY	: 0.75KW (1HP)
CURRENT	: 5A
S/NO. L	: _____ B
<b>RICH ELECTRIC CO., LTD.</b>	

Fig. 1 Nameplate Data

(b) Model Designation

<u>EI</u>	<u>-001</u>	<u>-L</u>
Eric Inverter	001= 1 Hp	L= 220V
	002= 2Hp	H= 440V
	⋮	
	⋮	
	005= 5Hp	
	⋮	
	⋮	

## 2 INSTALLATION

### CAUTION

- Lift the cabinet by the base. When moving the unit, never lift by the front cover. Otherwise, the main unit may be dropped causing damage to the unit.
- Mount the inverter on nonflammable material (i.e. metal). Failure to observe this caution can result in a fire.
- When mounting units in an enclosure, install a fan or other cooling device to keep the intake air temperature below 45°C. Overheating may cause a fire or damage to the unit.

This chapter describes the configuration, location and space when mounting the ERIC-9001.

---

## 2.1 CHOOSING A LOCATION TO MOUNT THE INVERTER

To ensure proper performance and long operating life, follow the recommendations below when choosing a location for installing the ERIC-9001. Make sure the inverter is protected from the following conditions:

- Extreme cold and heat.
  - Use only within ambient temperature range:  $-10^{\circ}\text{C}$  to  $+40^{\circ}\text{C}$
- Rain, moisture. (For enclosed wall-mounted type)
- Oil sprays, splashes
- Salt spray.
- Direct sunlight. (Avoid using outdoors.)
- Corrosive gases or liquids.
- Dust or metallic particles in the air. (For enclosed wall-mounted type)
- Physical shock, vibration.
- Magnetic noise. (Example: welding machines, power devices, etc.)
- High humidity.
- Radioactive materials.
- Combustibles: thinners, solvents, etc.

---

## 2.2 CLEARANCES

Install the ERIC-9001 vertically and allow sufficient clearances for effective cooling as shown in Fig. 3.




Fig.3 Clearances

**NOTE**

- 1.The clearances required at top/bottom and both sides are common in open chassis and enclosed wall-mounted.
  - 2.Allowable intake air temperature to the inverter:
    - Open chassis type :  $-10^{\circ}\text{C}$  to  $+45^{\circ}\text{C}$
    - Enclosed wall-mounted type :  $-10^{\circ}\text{C}$  to  $+40^{\circ}\text{C}$
  - 3.Ensure sufficient space for the sections at the upper and lower parts marked with \* in order to permit the flow of intake/exhaust air to/from the inverter
-

---

### 3 WIRING

#### WARNING

- Only commence wiring after verifying that the power supply is turned OFF.  
Failure to observe this warning can result in an electrical shock or a fire.
- Wiring should be performed only by qualified personnel.  
Failure to observe this warning can result in an electrical shock or a fire.
- When wiring the emergency stop circuit, check the wiring thoroughly before operation.  
Failure to observe this warning can result in personal injury.

#### CAUTION

- Verify that the inverter rated voltage coincides with the AC power supply voltage.  
Failure to observe this caution can result in personal injury or a fire.
- Do not perform a withstand voltage test of the inverter.  
It may cause semi-conductor elements to be damaged.
- To connect a braking resistor, braking resistor unit or braking unit, follow the procedures described in APPENDIX 3.  
Improper connection may cause a fire.
- Tighten terminal screws to the specified tightening torque.  
Failure to observe this caution can result in a fire.

This chapter describes the main circuit wiring and the control circuit wiring of the ERIC-9001.

### 3.1 CONNECTION DIAGRAM

Below is a connection diagram of the main circuit and control circuit. Using the digital operator, the motor can be operated by wiring the main circuit only.




Fig. 4 Connection Diagram





Layout of control circuit terminals

11	12(G)	13	14	15	16	17	25	26	27	33	18	19	20
1	2	3	4	5	6	7	8	21	22	23	9	10	



1. indicates shielded wires and indicates twisted-pair shielded wires.
2. Either control circuit terminal 13 or 14 can be used. (For simultaneous inputs, the two signals are added internally.)
3. Control circuit terminal 15/33 of +15 V/-15 V has a maximum output current capacity of 20 mA.
4. Multi-function analog output should be used for monitoring meters (e.g. output frequency meter) and should not be used for feedback control system.

## 3.2 WIRING THE MAIN CIRCUIT

### WARNING

- Make sure to ground the ground terminalⓄ .  
(Ground resistance 220V class: 100Ω or less, 440Vclass: 10Ω or less)  
Failure to observe this warning can result in an electrical shock or a fire.

### CAUTION

- Never connect the AC main circuit power supply to output terminals U, V and W.  
The inverter will be damaged and invalidate the guarantee.

#### (1) Wiring Precautions for Main Circuit Input

##### (a) Installation of Molded–case Circuit Breaker (MCCB)

Make sure to connect MCCBs or fuses between AC main circuit power supply and ERIC-9001 input terminals L1, L2 and L3 to protect wiring.

##### (b) Installation of Ground Fault Interrupter

When connecting a ground fault interrupter to input terminals L1, L2 and L3, select one that is not affected by high frequency.

##### (c) Installation of Magnetic Contactor

Inverters can be used without a magnetic contactor (MC) installed at the power supply side. When the main circuit power supply is shut OFF in the sequence, a magnetic contactor (MC) can be used instead of a molded–case circuit breaker (MCCB). However, when a magnetic contactor is switched OFF at the primary side, regenerative braking does not function and the motor coasts to a stop.

- 
- The load can be operated/stopped by opening/closing the magnetic contactor at the primary side. However, frequent switching may cause the inverter to malfunction.
  - When using a braking resistor unit, use a sequencer to break power supply side on overload relay trip contact. If the inverter malfunctions, the braking resistor unit may be burned out.

(d) Terminal Block Connection Sequence

Input power supply phases can be connected to any terminal regardless of the order of L1, L2 and L3 on the terminal block.

(e) Installation of AC Reactor

When connecting an inverter (220V/440V/15kW or less) to a large capacity power supply transformer (600kVA or more), or when switching a phase advancing capacitor, excessive peak current flows in the input power supply circuit, which may damage the converter section. In such cases, install a DC reactor (optional) between inverter ⊕1 and ⊕2 terminals or an AC reactor (optional) on the input side. Installation of a reactor is effective for improvement of power factor on the power supply side.

(f) Installation of Surge Suppressor

For inductive loads (magnetic contactors, magnetic relays, magnetic valves, solenoids, magnetic brakes, etc.) connected near the inverter, use a surge suppressor simultaneously.

(g) Prohibition of Installation of Phase Advancing Capacitor

If a phase advancing capacitor or surge suppressor is connected in order to improve the power factor, it may become overheated and damaged by inverter high harmonic components. Also, the inverter may malfunction because of overcurrent.

## (2) Wiring Precautions for Main Circuit Output

### (a) Connection of Terminal Block and Load

Connect output terminals U, V and W to motor lead wires U, V and W. Verify that the motor rotates in the forward direction (CCW: counterclockwise when viewed from the motor load side) with the forward run command. If the motor rotation is incorrect, exchange any two of output terminals U, V or W.

### (b) Strict Prohibition of Connection of Input Power Supply to Output Terminals

Never connect the input power supply to output terminals U, V and W.

### (c) Strict Prohibition of Short Circuiting or Grounding of Output Circuit

Never touch the output circuit directly or put the output line in contact with the inverter case. Otherwise, it may cause an electrical shock or grounding. In addition, never short circuit the output line.

### (d) Prohibition of Connection of Phase Advancing Capacitor or LC/RC Noise Filter

Never connect a phase advancing capacitor or LC/RC noise filter to the output circuit.

### (e) Avoidance of Installation of Magnetic Starter

Do not connect a magnetic starter or magnetic contactor to the output circuit. If the load is connected while the inverter is running, the inverter overcurrent protective circuit operates because of inrush current.

### (f) Installation of Thermal Overload Relay

An electronic overload protective function is incorporated into the inverter. However, connect a thermal overload relay when driving several motors with one inverter or when using a multi-pole motor. When using a thermal overload relay, set inverter constant L1-01 to 0. Additionally, for thermal overload relay, at 50Hz set the same rated current value as that described on the motor nameplate, or at 60Hz 1.1 times larger than the rated current value described on the motor nameplate.

(g) Wiring Distance between Inverter and Motor

If the total wiring distance between inverter and motor is excessively long and the inverter carrier frequency (main transistor switching frequency) is high, harmonic leakage current from the cable will adversely affect the inverter and peripheral devices.

If the wiring distance between inverter and motor is long, reduce the inverter carrier frequency as described below. Carrier frequency can be set by constant C6-01.

Table 2 Wiring Distance between Inverter and Motor

Wiring Distance between Inverter and Motor	Up to 50m	Up to 100m	More than 100m
Carrier Frequency (Set value of constant C6-01)	15kHz or less (15.0)	10kHz or less (10.0)	5kHz or less (5.0)

(3) Grounding

- Ground resistance  
220V class : 100Ω or less, 440V class : 10Ω or less.
- Never ground ERIC-9001 in common with welding machines, motors, or other large-current electrical equipment. Run all the ground wires in a conduit separate from wires for large-current electrical equipment.
- When using several ERIC-9001 units side by side, ground the units as shown in Fig. 5, (a) or (b). Do not loop the ground wires as shown in (c).




Fig.5 Grounding of Three ERIC-9001 Units

### 3.3 WIRING THE CONTROL CIRCUIT

The following table outlines the functions of the control circuit terminals.  
Wire according to each terminal function.

#### (1) Functions of Control Circuit Terminals

Table 3 Control Circuit Terminals

Classification	Terminal	Signal Function	Description	Signal Level	
Sequence Input Signal	1	Forward run/stop	Forward run when closed, stop when open	Photo-coupler insulation Input : +24 VDC 8 mA	
	2	Reverse run/stop	Reverse run when closed, stop when open		
	3	External fault input	Fault when closed, normal state when open		
	4	Fault reset input	Reset when closed		
	5	Master/Auxiliary change (Multi-step speed reference 1)	Auxiliary frequency reference when closed		
	6	Multi-step speed reference 2	Effective when closed		
	7	Jog reference	Jog run when closed		
	8	External baseblock	Inv. output stop when closed		
	11	Sequence control input common terminal	—		
Analog Input Signal	15	+15 V Power supply output	For analog command +15 V power supply	+15 V (Allowable current 20 mA max.)	
	33	-15 V Power supply output	For analog command -15 V power supply	-15 V (Allowable current 20 mA max.)	
	13	Master frequency reference	-10 to +10 V/-100% to +100% 0 to +10 V/100%	-10 to +10 V (20 kΩ), 0 to +10 V/(20 kΩ)	
	14		4 to 20 mA/100%.	4 to 20mA (250Ω)	
	16	Multi-function analog input	-10 to +10V/-100% to +100% 0 to +10 V/100%	Auxiliary analog input (H3-05)	-10 to +10V (20kΩ), 0 to +10V/(20kΩ)
	17	Common terminal for control circuit	0 V	—	
	12	Connection to shield sheath of signal lead	—	—	
Sequence Output Signal	9	During running (NO contact)	Closed when running	Multi-function contact output	Dry contact Contact capacity: 250 VAC 1 A or less 30 VDC 1 A or less
	10				
	25	Zero speed detection	Makes at min. freq. (E1-09) or less	Open collector output 48 V 50 mA or less	
	26	Speed agree detection	Makes when the freq. reaches to ±1 Hz of set freq.		
	27	Open collector output common	—	—	
	18	Fault contact output (NO/NC contact)	Fault when closed between terminals 18 and 20 Fault when open between terminals 19 and 20	Multi-function analog output	Dry contact Contact capacity: 250 VAC 1 A or less 30 VDC 1 A or less
19					
20					
Analog Output Signal	21	Frequency meter output	0 to +10 V/100% freq.	Multi-function analog monitor 1 (H4-01,H4-02)	0 to ±10 V Max. ±5% 2 mA or less
	22	Common			
	23	Current monitor	5 V/inverter rated current	Multi-function analog monitor 2 (H4-04,H4-05)	




Fig.6 Control Circuit Terminal Arrangement

---

## (2) Precautions on Control Circuit Wiring

- Separate control circuit wires 1 to 33 from main circuit wires L1, L2, L3, B1, B2, U, V, W,  $\ominus$ ,  $\oplus 1$ ,  $\oplus 2$ ,  $\oplus 3$  and other power cables to prevent erroneous operation caused by noise interference.
- Separate control circuit wires 9, 10, 18, 19, 20 (contact output) from wires 1 to 8, 21, 22, 23, 25, 26, 27, 33 and 11 to 17.
- Use twisted shielded or twisted-pair shielded wire for the control circuit line and connect the shielded sheath to the inverter terminal 12. See Fig. 7. Wiring distance should be less than 50 m.




Fig.7 Shielded Wire Termination

## 3.4 WIRING INSPECTION

After completing of installation and wiring, check for the following items. Never use control circuit buzzer check.

- Wiring is proper.
- Wire clippings or screws are not left in the unit.
- Screws are securely tightened.
- Bare wire in the terminal does not contact other terminals.

## 4 OPERATION

### WARNING

- Only turn ON the input power supply after replacing the front cover. Do not remove the cover while current is flowing.  
Failure to observe this warning can result in an electrical shock.
- When the retry function (L5-02) is selected, do not approach the inverter or the load, since it may restart suddenly after being stopped.  
(Construct machine system, so as to assure safety for personnel, even if the inverter should restart.) Failure to observe this warning can result in personal injury.
- Since the stop button can be disabled by a function setting, install a separate emergency stop switch.  
Failure to observe this warning can result in personal injury.
- If an alarm is reset with the operation signal ON, the inverter restarts automatically. Only reset the alarm after verifying that the operation signal is OFF.  
Failure to observe this warning can result in personal injury.

### CAUTION

- Never touch the heatsink or discharging resistor since the temperature is very high.  
Failure to observe this caution can result in harmful burns to the body.
- Since it is easy to change operation speed from low to high speed, verify the safe working range of the motor and machine before operation.  
Failure to observe this caution can result in personal injury and machine damage.
- Install a holding brake separately if necessary.  
Failure to observe this caution can result in personal injury.
- Do not change signals during operation.  
The machine or the inverter may be damaged.
- All the constants of the inverter have been preset at the factory. Do not change the settings unnecessarily.  
The inverter may be damaged. For supply voltage, follow Par. 4.3.

This chapter describes the basic operation procedures of the ERIC-9001.




## 4.1 OPERATION MODE SELECTION

The ERIC-9001 has two operation modes, LOCAL and REMOTE, as described below. These two modes can be selected by the digital operator "LOCAL/REMOTE" key only while the operation is stopped. The selected operation mode can be verified by observing the digital operator SEQ and REF LEDs as shown below. The operation mode is set to REMOTE (run by control circuit terminals 13 and 14 frequency reference and run command from a control circuit terminal) prior to shipment. Multi-function contact inputs from control circuit terminals 3 to 8 are enabled in both operation modes LOCAL/REMOTE.

- LOCAL : Both frequency reference and run command are set by the digital operator. SEQ and REF LEDs go OFF.
- REMOTE : Master frequency reference and run command can be selected as described below.

Table 4 Reference Selection in REMOTE Mode

Con-stant No.	Digital Operator Display	Name	Remarks
B1-01	Reference Source	Reference selection	0 : Master frequency reference from operator (D1-01) (Operator REF LED is OFF.) 1 : Master frequency reference from control circuit terminals 13 and 14 (Operator REF LED is ON.) 2 : Master frequency reference set by transmission (Operator REF LED blinks.) 3 : Master frequency reference set by option (Operator REF LED blinks.)
B1-02	Run Source	Operation method selection	0 : Master frequency reference from operator (D1-01) (Operator REF LED is OFF.) 1 : Master frequency reference from control circuit terminals 13 and 14 (Operator REF LED is ON.) 2 : Master frequency reference set by transmission (Operator REF LED blinks.) 3 : Master frequency reference set by option (Operator REF LED blinks.)



## 4.2 TEST RUN CHECKPOINTS

To assure safety, prior to initial operation, disconnect the machine coupling so that the motor is isolated from the machine. If initial operation must be performed while the motor is still coupled to the machine, use great care to avoid potentially hazardous conditions. Check the following items before a test run.

- Wiring and terminal connections are correct.
- No short circuit caused by wire clippings.
- Screw-type terminals are securely tightened.
- Motor is securely mounted.
- All items are correctly earthed (grounded) .

## 4.3 TEST RUN

### (1) Digital Operator Display at Power-up

When the system is ready for operation, turn ON the power supply. Verify that the inverter power up properly. If any problems are found, turn OFF the power supply immediately. The digital operator display illuminates as shown below when turning the power supply ON.




Fig. 8 Digital Operator Display at Power-up

## (2) Operation Check Points

Check the following items during operation.

- Motor rotates smoothly.
- Motor rotates in the correct direction.
- Motor does not have abnormal vibration or noise.
- Acceleration and deceleration are smooth.
- Current matches the load flow.
- Status indicator LEDs and digital operator display are correct.

## (3) Example of Basic Operation

### (a) Operation by Digital Operator

The diagram below shows a typical operation pattern using the digital operator.





















Fig. 9 Operation Sequence by Digital Operator

Table 5 Typical Operation by Digital Operator

Description	Key Sequence	Digital Operator Display
<p>① Power ON</p> <ul style="list-style-type: none"> <li>· Displays frequency reference value.</li> </ul>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Frequency Ref U1-01 = 0.00 Hz</div>
<p>↓</p> <p>Operation Condition Setting</p> <ul style="list-style-type: none"> <li>· Select LOCAL mode.</li> </ul>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">LOCAL REMOTE</div>	REMOTE LED OFF (SEQ. REF)
<p>↓</p> <p>② Forward Jog Run (6 Hz)</p> <ul style="list-style-type: none"> <li>· JOG run procedure (Runs while depressing JOG key.)</li> </ul>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">JOG</div>	
<p>↓</p> <p>③ Frequency Setting</p> <ul style="list-style-type: none"> <li>· Change reference value.</li> </ul>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">DATA ENTER</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Frequency Ref 0 00.00 Hz</div>
		Digit to be changed blinks.
	Change the value by depressing <div style="display: flex; justify-content: center; gap: 5px; margin-top: 5px;"> <div style="border: 1px solid black; padding: 2px;">▼</div> <div style="border: 1px solid black; padding: 2px;">▲</div> <div style="border: 1px solid black; padding: 2px;">↵</div> </div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Frequency Ref 01 5.00 Hz</div>
	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">DATA ENTER</div>	Entry Accepted
		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Frequency Ref 0 15.00 Hz</div>
<ul style="list-style-type: none"> <li>· Write-in set value.</li> </ul>		
		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Output Freq U1-02 = 0.00 Hz</div>
	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">ESC</div> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto; margin-top: 5px;">▲</div>	
		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Output Freq U1-02 = 15.00 Hz</div>
<p>↓</p> <p>④ Forward Run</p> <ul style="list-style-type: none"> <li>· Forward run (15 Hz)</li> </ul>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">○ RUN</div>	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Output Freq U1-02 = 15.00 Hz</div>
		RUN LED lights. FWD LED lights. <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto; margin-top: 5px;">● RUN</div>

Table 5 Typical Operation by Digital Operator (Cont'd)

Description	Key Sequence	Digital Operator Display
↓ ⑤ Frequency Reference Value Change (15 Hz to 60 Hz) · Select frequency reference value display.	  Depress twice.	
· Change set value.	Change the value by depressing   	
· Write-in set value.		
· Select output frequency monitor display.	 	
⑥ Reverse Run · Switch to reverse run.		 REV LED lights.
⑦ Stop · Decelerates to a stop.		 STOP LED lights. (RUN LED blinks during deceleration.) 

---

(b) Operation by Control Circuit Terminal Signal

The diagram below shows a typical operation pattern using the control circuit terminal signals.







Fig.10 Operation Sequence by Control Circuit Terminal Signal


Table 6 Typical Operation by Control Circuit Terminal Signal

Description	Key Sequence	Digital Operator Display
<p>① Power ON</p> <ul style="list-style-type: none"> <li>Displays frequency reference value.</li> <li>REMOTE mode is preset at the factory.</li> </ul>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Frequency Ref U1-01 = 0.00 Hz</div> <p>REMOTE LED lights. (SEQ, REF)</p>
<p>Output Frequency Display</p> <ul style="list-style-type: none"> <li>Switch to output frequency display.</li> </ul>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Output Freq U1-02 = 0.00 Hz</div>
<p>② Forward Jog Run (6Hz)</p> <ul style="list-style-type: none"> <li>Close between control circuit terminals 1 and 11 with 7 and 11 closed to perform JOG run.</li> <li>Open between terminals 1 and 11, 7 and 11 after verifying normal operation.</li> </ul>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Output Freq U1-02 = 6.00 Hz</div> <p>RUN LED lights. FWD LED lights.</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto; text-align: center;">● RUN</div>
<p>③ Frequency Setting</p> <ul style="list-style-type: none"> <li>Input frequency reference voltage (current) by control circuit terminal 13 or 14 and verify the input value by the digital operator.</li> </ul>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Frequency Ref U1-01 = 60.00 Hz</div> <p>For reference voltage 10V</p>
<p>Output Frequency Display</p> <ul style="list-style-type: none"> <li>Select output frequency monitor display.</li> </ul>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Output Freq U1-02 = 0.00 Hz</div>
<p>④ Forward Run</p> <ul style="list-style-type: none"> <li>Close between control circuit terminals 1 and 11 to perform forward run.</li> </ul>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Output Freq U1-02 = 60.00 Hz</div> <p>RUN LED lights. FWD LED lights.</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto; text-align: center;">● RUN</div>
<p>⑤ Stop</p> <ul style="list-style-type: none"> <li>Open between control circuit terminals 1 and 11 to stop operation.</li> </ul>		<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">Output Freq U1-02 = 0.00 Hz</div> <p>STOP LED lights. (RUN LED blinks during deceleration.)</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto; text-align: center;">● STOP</div>




## 5 SETTING OPERATION CONDITIONS

### 5.1 DIGITAL OPERATOR KEY DESCRIPTION



\* RUN or STOP LED changes in accordance with the following operations.



Note: Only a digit that is blinking can be changed.

Fig.11 Digital Operator Key Description

## 5.2 DIGITAL OPERATOR MODE SELECTION

The digital operator of the ERIC-9001 has the following four modes.

Table 7 Digital Operator Modes

Mode	Description
Operation	Inverter operation is enabled. Displays monitor value, fault trace or faults that occurred previously.
Initialize	Sets and reads language displayed on the digital operator, level to set/read constants and control method.
Programming	Sets/reads constants.
Modified Constants	Sets/reads constants changed from the values preset at the factory.



















Depressing the [MENU] key displays "Operation". Change the mode display by using  or  key and select a mode by the [DATA/ENTER] key. The following shows typical operation.

Table 8 Typical Operation of Mode Selection

Description	Key Sequence	Digital Operator Display	Remarks
· Displays Operation.			
· Change the mode. (Displays Initialize.)			
· Change the mode. (Displays Programming.)			
· Change the mode. (Displays Auto-Tuning.)			
· Change the mode. (Displays Modified Consts.)			
· Select Modified Consts.			Displays accel time and its setting when accel time has been changed.
· Return the display to Modified Consts.			
· Change the mode. (Displays Operation.)			

The mode can be changed even during operation. Even if the mode is changed to the programming mode to set/read constants during operation, the inverter continues operation. The inverter does not operate even if the run command is input, when the programming mode is selected and the inverter is stopped.

### 5.3 OPERATION MODE












The inverter can operate in this mode. Operation data or faults can be displayed. Each time when depressing  or  key, an item to be monitored is changed. If any fault occurs, the digital operator changes to the fault display automatically and returns to the previous display by the [> RESET] key.

Table 9 Typical Operation in Operation Mode

Description	Key Sequence	Digital Operator Display	Remarks
POWER ON *1			
Displays Operation.		** Main Menu ** Operation	
Select Operation.			
Displays frequency reference value setting.*1		Frequency Ref U1-01 = 60.00Hz	To set frequency reference, depress the [DATA/ENTER] key. The value to be set blinks.
Displays output frequency.*1		Output Freq U1-02 = 60.00 Hz	
Displays output current.*1		Output Current U1-03 = 12.3 A	
Displays output voltage.*1 *2		Output Voltage U1-06 = 200.0 VAC	
U2- □□ *3		Function U2 Fault Trace	
U3- □□ *3		Function U3 Fault History	
U1- □□ *3		Function U1 Monitor	

\*1 : Data to be displayed after the power supply ON can be selected by setting any constant among frequency reference value, output frequency, output current or selected monitor. (Initial setting is set to the output voltage monitor.)

\*2 : Another item to be displayed instead of output voltage can be selected by constant setting.
















\*3 : For items to be displayed such as U1-□□, U2-□□ and U3-□□, refer to Table A-4 "Monitor Constants List".

## (1) Changing Frequency Reference Value

( Example )

Frequency reference value is changed from 0.00Hz to 60.00Hz using the digital operator.

Table 10 Changing Frequency Reference Value

Description	Key Sequence	Digital Operator Display	Remarks
The inverter is in the LOCAL mode. (Can be operated from the keypad. )			
· Displays Operation.			
· Select Operation. (Displays frequency reference.)			
· Depress [DATA/ENTER] key. The value to be set blinks.			
· Change the value to 60.00Hz.	  		
· Write-in the constant.			
			Returns to the frequency reference value display after Entry Accepted is displayed for 0.5 second.
			









Note : Only the digit that is blinking can be changed.

(2) Monitor Display

( Example )

Monitoring DC bus voltage (U1-07) during frequency reference display.

Table 11 Typical Monitor Display Operation

Description	Key Sequence	Digital Operator Display	Remarks
· Displaying frequency reference.		Frequency Ref U1-01 = 60.00 Hz	
· Displays U1-□□ monitor.	 	Function U1 Monitor	
· Select U1-□□		Frequency Ref U1-01 = 60.00 Hz	
· Displays U1-07.	 	DC Bus Voltage U1-07 = 303 VDC	
· Returns to U1-□□ display.		Function U1 Monitor	
· Returns to frequency reference display.	 	Frequency Ref U1-01 = 60.00 Hz	











### (3) Fault Display

When detecting a fault, the ERIC-9001 displays the fault contents on the digital operator and activates fault contact output, the motor coasts to a stop. For the display at fault occurrence or troubleshooting, refer to Table 22 "Fault Diagnosis and Corrective Actions". Since the ERIC-9001 stores the information obtained at fault occurrence in the inverter, the information can be verified. For details, refer to Table A-4 "Monitor Constants List".

( Example )

Verifying the status at fault occurrence and resetting the fault when overcurrent occurs during operation at 60.00Hz.

Table 12 Typical Operation of Fault Display

Description	Key Sequence	Digital Operator Display	Remarks
· Displaying frequency reference.			Displays the fault.
· Overcurrent occurs.			
· Verify the status at fault occurrence.			Displays the status immediately before the fault occurred.
			
			
· Reset the fault.			By resetting the fault, the display entered just prior to the fault occurrence is returned.

## 5.4 INITIALIZE MODE

As described below, the language displayed on the digital operator, the access level to set/read constants or control method (V/f control, vector control) can be selected. Make sure to set this mode before use of the ERIC-9001. The following table shows the main constants for initialize mode.

Table 13 Initialize Mode











Constant No.	Digital Operator Display	Name	Description
A1-00	Select Language	Language selection (change enable during run)	0 : English
A1-01	Access Level	Access level (change enable during run)	0 : Exclusive for monitoring 1 : Constants for user selection (Constants to be set/read can be programmed by operator.) 2 : QUICK-START (Constants required for test run are set/read.) 3 : BASIC (Normally-used constants are set/read.) 4 : ADVANCED (All constants are set/read.)
A1-02	Control Method	Control method selection	0 : V/f control 1 : V/f control with PG feedback 2 : Open loop vector 3 : Flux vector
A1-03	Init Parameter	Reset to factory defaults.	0 : No Initialization 1110 : Initialization of user setting 2220 : 2-wire initialization 3330 : 3-wire initialization
A1-04	Enter Password	Password	Password setting

## (1) Changing Control Method

( Example )



The control method is changed from open loop vector to V/f control.


Table 14 Changing Control Method

Description	Key Sequence	Digital Operator Display	Remarks
· Displaying frequency reference.		Frequency Ref U1-01 = 60.00 Hz	
· Displays Operation.	MENU	** Main Menu ** Operation	
· Displays Initialize.	 	** Main Menu ** Initialize	
· Select Initialize.		Select Language English	When selecting Initialize, Select Language is displayed.
· Change the constant name. (Displays Control Method.)	 	Control Method Open Loop Vector	
· By depressing DATA/ENTER key, constant No. and set value are displayed.		A1-02 = 02 *** Open Loop Vector	
· Change the control method. (Displays V/F Control.)	 	A1-02 = 00 V/F Control	
· Select V/F Control.		Entry Accepted	After displaying Entry Accepted for 0.5 second, returns to the control method display.
· Return to Operation.	MENU	** Main Menu ** Operation	
· Select Operation to display frequency reference.		Frequency Ref U1-01 = 60.00 Hz	



## 5.5 PROGRAMMING MODE

The constants of the ERIC-9001 are composed of group symbols, function Nos. and serial Nos. for each function item as shown below. Use  or  key to change the group, function or name display and select one by [DATA/ENTER] key. For details of the constants, refer to Table A-5 "Constants List".



According to access level (A1-01) setting, there are four ways to set and read constants as described below.

Table 15 Constant Access Level

Access Level	Description
User Constant Selection	Displays the selected constant from the constant name.
QUICK-START Selection	Displays the constant selected by QUICK-START from the constant name.
BASIC Selection	Displays the constant selected by QUICK-START and BASIC from the function name.
ADVANCED Selection	Displays all constants from the group name.

( Example 1 )

Select QUICK-START and change the decel time (C1-02) from 10.0 to 20.0 seconds while frequency reference is displayed.

Table 16 Changing Constant Data when QUICK-START is Selected

Description	Key Sequence	Digital Operator Display	Remarks
· Displaying frequency reference.		Frequency Ref U1-01 = 60.00 Hz	
· Displays Operation	MENU	** Main Menu ** Operation	
· Displays Programming.	↓ ↑	** Main Menu ** Programming	
· Select Programming.	DATA ENTER	Reference Source Terminal	When selecting Programming, the constant name and setting are displayed.
· Change the constant name display. (Displays Decel Time.)	↓ ↑	Decel Time 1 C1-02 = 10.0 sec	
· Depress DATA/ENTER key. The value to be set blinks.	DATA ENTER	Decel Time 1 0.010.0 sec	
· Change the value to 20.0 seconds.	↓ ↑ →	Decel Time 1 00 2 0.0 sec	
· Write-in the constant.	DATA ENTER	Entry Accepted	After displaying Entry Accepted for 0.5 second, returns to the decel time display.
· Return the display to Programming.	MENU		
· Displays Operation.	↓ ↑	** Main Menu ** Operation	
· Select Operation to display frequency reference.	DATA ENTER	Frequency Ref U1-01 = 60.00 Hz	

( Example 2 )

Select BASIC and change the decel time (C1-02) from 10.0 to 20.0 seconds while frequency reference is displayed.


















Table 17 Changing Constant Data when BASIC is Selected

Description	Key Sequence	Digital Operator Display	Remarks
· Displaying frequency reference.		Frequency Ref U1-01 = 60.00 Hz	
· Displays Operation.	MENU	** Main Menu ** Operation	
· Displays Programming.	↓ ↑	** Main Menu ** Programming	
· Select Programming.	DATA ENTER	Function b1 Sequence	When selecting Programmig, Function b1 is displayed.
· Change the function display. (Displays Accel/Decel.)	↓ ↑	Function C1 Accel/Decel	Searches for C1.
· Select the function (accel/decel time).	DATA ENTER	Accel Time 1 C1-01 = 10.0 sec	
· Change the name display. (Displays Decel Time.)	↓ ↑	Decel Time 1 C1-02 = 10.0 sec	Displays C1-02.
· Depress DATA/ENTER key. The value to be set blinks.	DATA ENTER	Decel Time 1 .010.0 sec	
· Change the value to 20.0 seconds.	↓ ↑ RESET	Decel Time 1 002.0.0 sec	
· Write-in the constant.	DATA ENTER	Entry Accepted	After displaying Entry Accepted for 0.5 second, returns to decel time display.
· Return to Operation.	MENU	** Main Menu ** Operation	
· Select Operation to display frequency reference.	DATA ENTER	Frequency Ref U1-01 = 60.00 Hz	

( Example 3 )

Select ADVANCED and change the decel time (C1-02) from 10.0 to 20.0 seconds while frequency reference is displayed.

Table 18 Changing Constant Data when ADVANCED is Selected

Description	Key Sequence	Digital Operator Display	Remarks
· Displaying frequency reference.		Frequency Ref U1-01 = 60.00 Hz	
· Displays Operation.		** Main Menu ** Operation	
· Displays Programming.	 	** Main Menu ** Programming	
· Select Programming.		Group b Application	When selecting the programming mode, the group menu is displayed.
· Change the group name. (Displays Tuning.)	 	Group C Tuning	
· Select the group. (Selects Tuning group.)		Function C1 Accel/Decel	When selecting the group, the function menu is displayed. Select a function name using $\wedge$ or $\vee$ key if necessary.
· Select the function. (Selects accel/decel time.)		Accel Time 1 C1-01 = 10.0 sec	When selecting the function, the constant name is displayed.
· Change the constant name. (Displays Decel Time.)	 	Decel Time 1 C1-02 = 10.0 sec	Displays C1-02.
· Depress DATA/ENTER key. The value to be set blinks.		Decel Time 1 0 010.0 sec	
· Change the value to 20.0 seconds.	  	Decel Time 1 00 2 0.0 sec	
· Write-in the constant.		Entry Accepted	After displaying Entry Accepted for 0.5 second, returns to decel time display.
· Return to Operation. (Displays Operation.)		** Main Menu ** Operation	
· Select Operation to display frequency reference.		Frequency Ref U1-01 = 60.00 Hz	

## 5.6 MODIFIED CONSTANTS MODE

Compares the constant values preset at the factory with the values changed by the user, and displays the constants changed from the preset constants automatically. In the modified constants mode, constants can be read; in addition, they can also be set or changed.

( Example )

Read the constants C1-01 (accel time) and E1-01 (input voltage) when the factory settings have been changed. In addition, change the setting of E1-01 (input voltage) from 210V to 230V in this mode.

Table 19 Typical Operation in Modified Constants Mode

Description	Key Sequence	Digital Operator Display	Remarks
· Displaying frequency reference.		Frequency Ref U1-01 = 60.00 Hz	
· Displays Operation.	MENU	** Main Menu ** Operation	
· Displays Modified Consts.	✓ ▲	** Main Menu ** Modified Consts	
· Select the Modified Consts.	DATA ENTER	Accel Time 1 C1-01 = 20.0 Sec	When selecting Modified Consts the constants which have been changed from factory settings are displayed.
· Displays the next-to-be-changed constant. (Displays input voltage.)	✓ ▲	Input Voltage E1-01 = 210 VAC	
· Depress DATA/ENTER key. The value to be set blinks.	DATA ENTER	Input Voltage 2 10 VAC	
· Change the value to 230V.	✓ ▲ RESET	Input Voltage 2 3 0 VAC	
· Write-in the constant.	DATA ENTER	Entry Accepted	After displaying Entry Accepted for 0.5 second, returns to input voltage display.
· Displays the next-to-be-changed constant.	✓ ▲	Accel Time 1 C1-01 = 20.0 sec	
· Returns to Operation.	MENU	** Main Menu ** Operation	
· Select Operation to display frequency reference.	DATA ENTER	Frequency Ref U1-01 = 60.00 Hz	

## 6 MAINTENANCE AND INSPECTION

### WARNING

- Never touch high-voltage terminals in the inverter.  
Failure to observe this warning can result in an electrical shock.
- Replace all protective covers before powering up the inverter. To remove the cover, make sure to shut OFF the molded-case circuit breaker.  
Failure to observe this warning can result in an electrical shock.
- Perform maintenance or inspection only after verifying that the CHARGE LED goes OFF, after the main circuit power supply is turned OFF.  
The capacitors are still charged and can be dangerous.
- Only authorized personnel should be permitted to perform maintenance, inspections or parts replacement.  
[Remove all metal objects (watches, bracelets, etc.) before operation.]  
(Use tools which are insulated against electrical shock.)  
Failure to observe this warning can result in an electrical shock.

### CAUTION

- The control PC board employs CMOS ICs. Do not touch the CMOS elements.  
They are easily damaged by static electricity.
- Do not connect or disconnect wires or connectors while power is applied to the circuit.  
Failure to observe this caution can result in personal injury.

This chapter describes basic maintenance and inspection procedures for the ERIC-9001.

## 6.1 PERIODIC INSPECTION

The ERIC-9001 will function longer if it is kept clean, cool and dry, while observing the precautions listed in Par. 2.3. Check for tightness of electrical connections, discoloration or other signs of overheating or aging. Use Table 20 as your inspection guide. Before servicing, turn OFF AC main circuit power and be sure that the CHARGE LED is OFF.

Table 20 Periodic Inspection

Component	Check	Corrective Action
External Terminals, Unit Mounting Bolts, Connectors, etc.	Loose screws	Tighten.
	Loose connectors	Tighten.
Heatsink	Build-up of dust and dirt	Blow with dry compressed air of $39.2 \times 10^4$ to $58.8 \times 10^4$ Pa (4 to $6 \text{ kg}\cdot\text{cm}^{-2}$ ) pressure.
Printed Circuit Board	Accumulation of conductive dust or oil.	Blow with dry compressed air of $39.2 \times 10^4$ to $58.8 \times 10^4$ Pa (4 to $6 \text{ kg}\cdot\text{cm}^{-2}$ ) pressure. If dust and oil cannot be removed, replace the board.
Cooling Fan	For abnormal noise and vibration. Whether the cumulative operation time exceeds 20,000 hours or not.	Replace the cooling fan.
Power Elements	Accumulation of dust and dirt	Blow with dry compressed air of $39.2 \times 10^4$ to $58.8 \times 10^4$ Pa (4 to $6 \text{ kg}\cdot\text{cm}^{-2}$ ) pressure.
Smoothing Capacitor	Discoloration or odor	Replace the capacitor or inverter unit.

## 6.2 PARTS REPLACEMENT SCHEDULE (GUIDELINES)

Replace the following parts periodically, for a long, safe, trouble free working life of ERIC-9001.

Table 21 Parts Replacement Schedule

Parts	Interval (Approx.)	Remarks
Cooling Fan	2 to 3 years	Replace with new one.
Smoothing Capacitor	5 years	Replace with new one. (Decided after inspection.)
Breakers or Relays	---	Decided after inspection.
Fuse	10 years	Replace with new one.
Aluminum Electrolytic Capacitor on PC Board	5 years	Replace with new one. (Decided after inspection.)

**NOTE**

Operating conditions are as follows:

Ambient temperature : 30°C yearly average

Load factor : 80% or below

Operation rate : 12 hours or below /day



---

## 7 TROUBLESHOOTING

This chapter describes the inverter fault display and the fault contents caused by motor / machine malfunctions and the corrective actions to be taken.

### 7.1 FAULT DIAGNOSIS AND CORRECTIVE ACTIONS

- (1) When the ERIC-9001 detects a fault, the fault is displayed on the digital operator and activates the fault contact output and the motor coasts to a stop. Check the cause in the table below and take the corrective actions.
- (2) If the inspections or corrective actions described cannot solve the problem, contact your RICH ELECTRIC representative immediately.
- (3) To restart, turn ON the reset input signal or depress [>RESET] key or shut OFF the main circuit power supply once, to reset the stop status.

Table 22 Fault Diagnosis and Corrective Actions

Fault Display	Description	Details	Corrective Action	Rank* (Standard Value)
UV 1 DC Bus Undervolt	Main circuit undervoltage (PUV)	Undervoltage in the direct current main circuit during running. Detection level 220 V class: Approx. 190 V or less 440 V class: Approx. 380 V or less	<ul style="list-style-type: none"> <li>· Check the power supply wiring.</li> <li>· Correct the line voltage.</li> </ul>	A
UV 2 CTL PS Undervolt	Control circuit undervoltage (CUV)	Undervoltage in the control circuit during running.		A
UV 3 MC Answerback	MC fault	The pre-charge contactor opened during running.		A
UV Under Voltage	Momentary power loss	<ul style="list-style-type: none"> <li>· The main circuit direct current voltage fell below the PUV level.</li> <li>· The control power source fell below the CUV level.</li> <li>· The pre-charge contactor opened.</li> </ul>	—	B
OC Overcurrent	Overcurrent (OC)	The inverter output current exceeded the OC level.	<ul style="list-style-type: none"> <li>· Check the motor coil resistance.</li> <li>· Extend the accel/decel time.</li> <li>· Check the motor insulation.</li> <li>· Multi-meter check</li> </ul>	A
GF Ground Fault	Grounding (GF) (Earth fault)	Inverter output grounding current exceeded 50% of inverter rated current.	<ul style="list-style-type: none"> <li>· Check that motor insulation has not deteriorated.</li> <li>· Check that connection between inverter and motor is not damaged.</li> </ul>	A
OV Overvoltage	Overvoltage (OV)	The main circuit direct current voltage exceeded the OV level. Detection level 220 V class: Approx. 440 V 440 V class: Approx. 880 V	Extend the deceleration time, add braking circuit.	A
SC Short Circuit	Load short-circuit (SC)	Inverter output (load) is short-circuited.	<ul style="list-style-type: none"> <li>· Check the motor coil resistance.</li> <li>· Check the motor insulation.</li> </ul>	A
P UF DC Bus Fuse Open	Fuse blown (FU)	<ul style="list-style-type: none"> <li>· The direct current circuit fuse is blown.</li> <li>· The output transistors were damaged.</li> </ul>	Check for damaged transistor, load side short circuit, grounding, etc.	A
OH Heatsink Over tmp	Heatsink overheat (OH1)	The transistor heatsink temperature exceeded the allowable value.	Check the fan and ambient temperature.	A
OL 1 Motor Overloaded	Motor overload (OL1)	Inverter output exceeded the motor overload level.	Reduce the load.	A
OL 2 Inv Overloaded	Inverter overload (OL2)	Inverter output exceeded the inverter overload level.	Reduce the load, extend the acceleration time.	A
PF Input Pha Loss	Input open-phase	<ul style="list-style-type: none"> <li>· Inverter input power supply has open-phase.</li> <li>· Large unbalance in input voltage.</li> </ul>	<ul style="list-style-type: none"> <li>· Check the line voltage.</li> <li>· Re-tighten the input terminal screws.</li> </ul>	A
LF Output Pha Loss	Output open-phase	Inverter output has open-phase.	<ul style="list-style-type: none"> <li>· Check the output wiring.</li> <li>· Check the motor impedance.</li> <li>· Re-tighten the output terminal screws.</li> </ul>	A

Table 22 Fault Diagnosis and Corrective Actions (Cont'd)

Fault Display	Description	Details	Corrective Action	Rank* (Standard Value)
RR Dyn Brk Transistor	Braking transistor failure	The braking transistor has failed.	Replace the inverter.	A
RH Dyn Brk Resistor	Braking resistor unit overheat	The braking resistor unit temperature has exceeded the allowable value. (Protects only inverter built-in type)	Reduce the regenerative load.	A
OS Over speed	Overspeed (OS)	The motor speed exceeded the overspeed level.	—	A
PGO PG open	PG open circuit (PGO)	The PG line is broken.	· Check the PG line. · Check the condition of the motor lock or the load.	A
DEV Speed Deviation	Speed deviation (DEV)	The deviation of the speed reference and speed feedback exceeded the regulation level.	Check the load.	B
EF External Fault	Operation reference fault (External)	Both FWD and REV run commands were closed for 500 ms or more.	Check sequence circuit.	B
EF 3 External Fault 3	External fault at terminal 3	Fault occurred in the external control circuit.	Check the condition of the input terminal. If the LED lights when terminal is not connected, replace the inverter.	A
EF 4 External Fault 4	External fault at terminal 4			B
EF 5 External Fault 5	External fault at terminal 5			B
EF 6 External Fault 6	External fault at terminal 6			B
EF 7 External Fault 7	External fault at terminal 7			B
EF 8 External Fault 8	External fault at terminal 8			B
OPE 0 1 kVA Selection	kVA selection fault (OPE01)	kVA selection fault	Check and set the constant data.	C
OPE 0 2 Limit	Constant setting range fault (OPE02)	Constant data is out of range.	Check the constant data settings.	C
OPE 0 3 Terminal	Multi-function contact input selection fault (OPE03)	<ul style="list-style-type: none"> <li>· In H1-01 to H1-06 settings:</li> <li>· The same values are set except for F, FF and 20 to 2F.</li> <li>· Both UP/DOWN and HOLD commands are set.</li> <li>· UP and DOWN commands are not set at the same time.</li> <li>· Two or more HOLD, UP/DOWN, sample/hold commands are set.</li> <li>· Two or more external baseblock and speed search 1, 2, 3 commands are set.</li> <li>· In B5-01 setting, both PID control and UP/DOWN commands are set.</li> <li>· In H3-09 setting, terminal 13/14 selection and the value other than "Not used" are set at the same time.</li> </ul>	Check the constants.	C

Table 22 Fault Diagnosis and Corrective Actions (Cont'd)


Fault Display	Description	Details	Corrective Action	Rank* (Standard Value)
OPE05 Sequence Select	Option reference selection fault (OPE05)	<ul style="list-style-type: none"> <li>In B1-01 setting, C-option is not connected although frequency reference from C-option is selected.</li> <li>In B1-02 setting, C-option is not connected although run command from C-option is selected.</li> </ul>	Check the constants.	C
OPE06 PG Opt Missing	Control method selection fault (OPE06)	<ul style="list-style-type: none"> <li>In A1-02 setting, PG is not connected although V/f control with PG feedback is selected.</li> <li>PG-B is not connected although flux vector control is selected.</li> </ul>	Check the constants.	C
OPE07 Analog Selection	Multi-function analog input selection fault (OPE07)	<ul style="list-style-type: none"> <li>In H3-05 and H3-09 settings, the same values are set except for 0 and 1F.</li> <li>While AI-14B is connected, "0" is set in F2-01 and option/inverter selection is set in multi-function contact input.</li> </ul>	Check the constants.	C
OPE10 V/f	V/f data setting fault (E1-04 to E1-10)	<p>When the settings of E1-04 to E1-10 do not satisfy the following conditions:</p> <ul style="list-style-type: none"> <li><math>F_{Max} \geq F_A &gt; F_B \geq F_{Min}</math>. (E1-04)(E1-06)(E1-07)(E1-09)</li> </ul> 	Check the constants.	C
OPE11 FC/ On-Dly	Constant setting fault	<p>When one of the following setting fault occurs:</p> <ul style="list-style-type: none"> <li>Carrier frequency upper limit (C6-01) &gt; 5kHz, and Carrier frequency lower limit (C6-02) ≤ 5kHz</li> <li>Carrier frequency proportional gain (C6-03) &gt; 6 and (C6-01) &lt; (C6-02)</li> </ul>	Check the constants.	C
ERR EEPROM R/W Err	EEPROM writing fault (ERR)	EEPROM internal data did not match when initializing the constant.	Replace the control card.	B
CALL Serial Com Call	SI-B transmission error	Control data was not received normally when power supply is turned ON.	Check transmission devices and transmission signals.	C
CE Memobus Com Err	Transmission error	Control data was not received normally when power supply is turned ON.	Check transmission devices and transmission signals.	A
CPF00 COM-ERR(OP&INV)	Control circuit fault 1 (CPF00) (Digital operator transmission fault)	<ul style="list-style-type: none"> <li>Transmission between the inverter and digital operator cannot be established 5 seconds after supplying power.</li> <li>MPU peripheral element check fault (initial)</li> </ul>	<ul style="list-style-type: none"> <li>Insert the digital operator connector again.</li> <li>Check the control circuit wiring.</li> <li>Replace the control card.</li> </ul>	A
CPF01 COM-ERR(OP&INV)	Control circuit fault 2 (CPF01) (Digital operator transmission fault)	<ul style="list-style-type: none"> <li>Transmission between the inverter and digital operator is established once after supplying power, but later transmission fault continues for more than 2 seconds.</li> <li>MPU peripheral element check fault (online)</li> </ul>	<ul style="list-style-type: none"> <li>Insert the digital operator connector again.</li> <li>Check the control circuit wiring.</li> <li>Replace the control card.</li> </ul>	A

Table 22 Fault Diagnosis and Corrective Actions (Cont'd)

Fault Display	Description	Details	Corrective Action	Rank* (Standard Value)
C P F 0 2 BB Circuit Err	Baseblock circuit fault (CPF02)	Inverter control unit fault.	Replace the control card.	A
C P F 0 3 EEPROM Error	EEPROM fault (CPF03)			A
C P F 0 4 Internal A/D Err	CPU internal A/D converter fault (CPF04)			A
C P F 0 5 External A/D Err	CPU external A/D converter fault (CPF05)			A
C P F 0 6 Option Error	Option connection fault (CPF06)	The option card is not installed correctly.	Install the option card again.	A
C P F 2 0 Option A/D Error	A/D converter fault in analog speed reference card (CPF20)	Option card (AI-14B) A/D converter fault	Replace the option card.	A

\* The ranks are classified as follows:

Rank A: Major fault (Motor coasts to a stop, operator indication lights, and FAULT contact is output.)

Rank B: Fault (Operation continues, operator indication blinks, no FAULT contact is output, and minor fault contact is output (when multi-function output is selected).)

Rank C: Warning (Operation cannot be performed, operator indication lights, no FAULT contact is output, no minor fault contact is output.)

## 7.2 MOTOR FAULTS AND CORRECTIVE ACTIONS

- (1) If any of the following faults occurs in the motor, check the cause and provide the relevant corrective action.
- (2) If these inspections and corrective actions cannot solve the problem, contact your RICH ELECTRIC representative immediately.

Table 23 Motor Faults and Corrective Actions

Fault	Check Point	Corrective Action
Motor does not rotate.	Power supply voltage applied to power supply terminals L1, L2, L3? CHARGE LED is ON?	<ul style="list-style-type: none"> <li>· Turn ON power supply.</li> <li>· Turn OFF power supply, and then ON again.</li> <li>· Check power supply voltage.</li> <li>· Make sure terminal screws are tight.</li> </ul>
	Use rectifier type voltmeter to test. Voltage output to output terminals U, V, W correct?	Turn OFF power supply, then turn ON again.
	Motor locks due to excessive load?	Reduce the load and release the lock.
	Fault displayed in operator display?	Check troubleshooting table.
	FWD or REV run command entered?	Check the wiring.
	Frequency setting voltage entered?	<ul style="list-style-type: none"> <li>· Correct the wiring.</li> <li>· Check frequency setting voltage.</li> </ul>
	Operation mode setting correct?	With the operator, check the operation mode selection.
Motor rotation reverses.	Wiring of terminals U, V, W correct?	Match wiring to the phase order of the motor leads U, V, W.
	FWD and REV wiring run signals entered?	Correct the wiring.
Motor rotates, but variable speed not available.	Wiring of frequency setting circuit correct?	Correct the wiring.
	Operation mode setting correct?	With the operator, check the operation mode selection.
	Load excessively large?	Reduce the load.
Motor r/min too high or too low.	Motor ratings (number of poles, voltage) correct?	Check motor nameplate specifications.
	Accel/decel speed change ratio for gears, etc. correct?	Check speed changer (gears, etc.)
	Maximum frequency set value correct?	Check the maximum frequency set value.
	Use rectifier voltmeter. Voltage between motor terminals not excessively reduced?	Check V/f characteristics values.
Motor r/min not stable during operation.	Load excessively large?	Reduce the load.
	Load variation excessively large?	<ul style="list-style-type: none"> <li>· Reduce the load variation.</li> <li>· Increase inverter motor capacity.</li> </ul>
	3-phase or single-phase power supply used? For 3-phase power supply, open phase?	<ul style="list-style-type: none"> <li>· For 3-phase power supply, check the wiring if power supply is open phase.</li> <li>· For single-phase power supply, connect AC reactor to the power supply.</li> </ul>

# APPENDIX 1 SPECIFICATIONS

Table A-1 220V Class Specifications

Inverter Model E1- <input type="text"/>	001-L	002-L	003-L	005-L	007-L	010-L	015-L	020-L	025-L	030-L	040-L	050-L	060-L	075-L	100-L
Max. Applicable Motor output* kw	1.1	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75
Inverter Capacity Hp	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100
Rated Output Current A	6	8	11	17.5	25	33	49	64	80	96	130	160	183	224	300
Max. Output Voltage	3-Phase, 200/208/220/230 V (Proportional to input voltage)														
Rated Output Frequency	Up to 400 Hz available by programming														
Rated Input Voltage and Frequency	3-Phase 200/208/220 V 50 Hz 200/208/220/230 V 60 Hz														
Allowable Voltage Fluctuation	+ 10%, - 15%														
Allowable Frequency Fluctuation	± 5%														
Control Method	Sine wave PWM														
Starting Torque	150%/1Hz (150% / or / min with PG)														
Speed Control Range	1:100(1:1000 with PG)														
Speed Control Accuracy	± 0.2% (± 0.02% with PG)														
Speed Response	5 Hz (30Hz with PG)														
Torque Limit	Available (Parameter setting, 4 steps can be changed)														
Torque Accuracy	± 5%														
Torque Response	20 Hz(40 Hz with PG)														
Frequency Control Range	0.1 to 400 Hz														
Frequency Accuracy	Digital command: 0.01% (-10°C to +40°C) Analog command: 0.1% (25°C ± 10°C)														
Frequency Resolution	Digital operator reference: ± 0.01 Hz Analog reference: 0.05 Hz/60 Hz (11 bit+code)														
Output Frequency Resolution	0.01 Hz														
Overload Capacity	150% of rated output current for 1 minute														
Frequency Setting Signal	-10 to 10V, 0 to 10V, 4 to 20 mA														
Accel/Decel Time	0.01 to 6000.0 sec (Accel/decel time setting independently, 4 steps available)														
Braking Torque	Approx. 20%														
Motor Overload Protection	Protected by electronic thermal overload relay														
Instantaneous Overcurrent	Motor coasts to a stop at approx. 200% of inverter rated current.														
Blown Fuse Protection	Motor coasts to a stop by blown-fuse.														
Overload	Motor coasts to a stop after 1 minute at 150% of rated output current.														
Overvoltage	Motor coasts to a stop if converter output voltage exceeds 410 V.														
Undervoltage	Motor coasts to a stop if converter output voltage drops to 190 V or below.														
Momentary Power Loss	Immediately stop by 15 ms and above momentary power loss. (Factory setting) Continuous operation during power loss less than 2 sec is equipped as standard.														
Heatsink Overheat	Protected by thermistor														
Stall Prevention	Stall prevention during accel/deccl and constant speed operation														
Ground Fault	Protected by electronic circuit (Overcurrent level)														
Power Charge Indication	Charge LED stays ON until bus voltage drops below 50 V.														
Ambient Temperature	-10°C to +40°C (Enclosed wall-mounted type) -10°C to +45°C (Open chassis type)														
Humidity	90% RH or less														
Storage Temperature	-20°C to +60°C														
Location	Indoor (protected from corrosive gases and dust)														
Elevation	1000 m or less														
Vibration	9.81m/s <sup>2</sup> (1G) less than 20 Hz, up to 1.96m/s <sup>2</sup> (0.2G) at 20 to 50 Hz														

# APPENDIX 1 SPECIFICATIONS


Table A-2 440V Class Specifications

Inverter Model E1	001-H	002-H	003-H	005-H	007-H	010-H	015-H	020-H	025-H	030-H	040-H	050-H	060-H	075-H	100-H	150-H	200-H	250-H	300-H	400-H
Max. Applicable Motor output* kW	1.1	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	110	160	185	220	300
Inverter Capacity Hp	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100	150	200	250	300	400
Rated Output Current A	3.4	4.8	6.2	5	14	18	27	34	41	48	65	80	96	128	165	224	302	340	450	605
Max. Output Voltage	3-Phase 380/400/415/440/460 V (Proportional to input voltage)																			
Rated Output Frequency	Up to 400 Hz available by programming																			
Rated Input Voltage and Frequency	3-Phase 380/400/440/460 V 50/60 Hz																			
Allowable Voltage Fluctuation	+ 10%, - 15%																			
Allowable Frequency Fluctuation	± 5%																			
Control Method	Sine wave PWM																			
Starting Torque	150%/1Hz (150% / or / min with PG)																			
Speed Control Range	1:100(1:1000 with PG)																			
Speed Control Accuracy	± 0.2% (± 0.02% with PG)																			
Speed Response	5 Hz (30Hz with PG)																			
Torque Limit	Available (Parameter setting, 4 steps can be changed)																			
Torque Accuracy	± 5%																			
Torque Response	20 Hz(40 Hz with PG)																			
Frequency Control Range	0.1 to 400 Hz																			
Frequency Accuracy	Digital command: ± 0.01% (-10°C to +40°C) Analog command: ± 0.1% (25°C ± 10°C)																			
Frequency Resolution	Digital operator reference: ± 0.01 Hz Analog reference: ± 0.03 Hz/60 Hz (11 bit+code)																			
Output Frequency Resolution	0.01 Hz																			
Overload Capacity	150% of rated output current for 1 minute																			
Frequency Setting Signal	-10 to 10V, 0 to 10V, 4 to 20 mA																			
Accel/Decel Time	0.01 to 6000.0 sec (Accel/decel time setting independently, 4 steps available)																			
Braking Torque	Approx. 20%																			
Motor Overload Protection	Protected by electronic thermal overload relay																			
Instantaneous Overcurrent	Motor coasts to a stop at approx. 200% of inverter rated current.																			
Blown Fuse Protection	Motor coasts to a stop by blown-fuse.																			
Overload	Motor coasts to a stop after 1 minute at 150% of rated output current.																			
Overvoltage	Motor coasts to a stop if converter output voltage exceeds 820 V.																			
Undervoltage	Motor coasts to a stop if converter output voltage drops to 380 V or below.																			
Momentary Power Loss	Immediately stop by 15 ms and above momentary power loss. (Factory setting) Continuous operation during power loss less than 2 sec is equipped as standard.																			
Heatsink Overheat	Protected by thermistor																			
Stall Prevention	Stall prevention during accel/decel and constant speed operation																			
Ground Fault	Protected by electronic circuit (Overcurrent level)																			
Power Charge Indication	Charge LED stays ON until bus voltage drops below 50 V.																			
Ambient Temperature	-10°C to +40°C (Enclosed wall-mounted type) -10°C to +45°C (Open chassis type)																			
Humidity	90% RH or less																			
Storage Temperature	-20°C to +60°C																			
Location	Indoor (protected from corrosive gases and dust)																			
Elevation	1000 m or less																			
Vibration	9.81m/s <sup>2</sup> (1G) less than 20 Hz, up to 1.96m/s <sup>2</sup> (0.2G) at 20 to 50 Hz																			






## APPENDIX 2 DIMENSIONS




TYPE FORM			DIMENSION mm							
Volt	220V	380V	A	B	C	D	E	F	G	H
Fig.1	1-5	1-5	360	342	220	202	165	185		
	7 1/2-10	7 1/2-15	445	430	275	202	210	230		
	15-25	20-30	555	540	275	200	230			
	30-40	40-60	695	677.5	320	240	380			
Fig.2	50-60	75-125	800	780	395	105	350	320	96	215
Fig.3	75-100	150-200	1080	1020	600	20	400			
Fig.4	REMOTE BOX		140	130	60	30	40	100	RANEL CUT 56×120	

## APPENDIX 3 TYPICAL CONNECTION DIAGRAM


### 3.1 BRAKING UNIT AND BRAKING RESISTOR UNIT



### 3.2 WITH TRANSISTOR OPEN COLLECTOR FOR OPERATION SIGNAL



### 3.3 WITH CONTACT OUTPUT, OPEN COLLECTOR OUTPUT



## APPENDIX 4    CONSTANTS LIST

Table A-4    Monitor Constants List

Digital Operator Function Display	Digital Operator Display	Constant No.	Constant Name	Unit	Control Method (○=Monitor enable, ×=Monitor disable)			
					V/f control	V/f with PG Feed-back	Open Loop Vector	Flux Vector
Monitor	Frequency Ref	U1-01	Frequency reference	0.01Hz	○	○	○	○
	Output Freq	U1-02	Output frequency	0.01Hz	○	○	○	○
	Output Current	U1-03	Output current	0.1A	○	○	○	○
	Control Method	U1-04	Control method	—	○	○	○	○
	Motor Speed	U1-05	Motor speed	0.01Hz	×	○	○	○
	Output Voltage	U1-06	Output voltage	0.1V	○	○	○	○
	DC Bus Voltage	U1-07	DC bus voltage	1V	○	○	○	○
	Output kWatts	U1-08	Output power	0.1kW	○	○	○	○
	Torque Reference	U1-09	Torque reference (internal)	0.1%	×	×	○	○
	Input Term Sts	U1-10	Input terminal status	—	○	○	○	○
	Output Term Sts	U1-11	Output terminal status	—	○	○	○	○
	Int Ctl Sts 1	U1-12	Internal control status	—	○	○	○	○
	Elapsed Time	U1-13	Cumulative operation time	1H	○	○	○	○
	CPU ID No	U1-14	PROM No. (at FLASH side)	—	○	○	○	○
Fault Trace	Current Fault	U2-01	Current fault	—	○	○	○	○
	Last Fault	U2-02	Last fault	—	○	○	○	○
	Frequency Ref	U2-03	Frequency reference at fault	0.01Hz	○	○	○	○
	Output Freq	U2-04	Output frequency at fault	0.01Hz	○	○	○	○
	Output Current	U2-05	Output current at fault	0.1%	○	○	○	○
	Motor Speed	U2-06	Motor speed at fault	0.01Hz	×	○	○	○
	Output Voltage	U2-07	Output voltage reference at fault	0.1V	○	○	○	○
	DC Bus Voltage	U2-08	DC bus voltage at fault	1V	○	○	○	○
	Output kWatts	U2-09	Output power at fault	0.1kW	○	○	○	○
	Torque Reference	U2-10	Torque reference at fault	0.1%	×	×	○	○
	Input Term Sts	U2-11	Input terminal status at fault	—	○	○	○	○
	Output Term Sts	U2-12	Output terminal status at fault	—	○	○	○	○
	Inverter Status	U2-13	Operation status at fault	—	○	○	○	○
	Elapsed Time	U2-14	Cumulative operation time at fault	1H	○	○	○	○

Table A-4 Monitor Constants List (Cont'd)

Digital Operator Function Display	Digital Operator Display	Constant No.	Constant Name	Unit	Control Method (○=Monitor enable, ×=Monitor disable)			
					V/f control	V/f with PG Feedback	Open Loop Vector	Flux Vector
Fault History	Last Fault	U3-01	Most recent fault	—	○	○	○	○
	Fault Message 2	U3-05	Cumulative operation time at fault	1H	○	○	○	○
	Fault Message 3	U3-02	Second most recent fault	—	○	○	○	○
	Fault Message 4	U3-06	Accumulated time of second fault	1H	○	○	○	○
	Elapsed Time 1	U3-03	Third most recent fault	—	○	○	○	○
	Elapsed Time 2	U3-07	Accumulated time of third fault	1H	○	○	○	○
	Elapsed Time 3	U3-04	Fourth / Oldest fault	—	○	○	○	○
	Elapsed Time 4	U3-08	Accumulated time of fourth / oldest fault	1H	○	○	○	○

Note : If another fault occurs (i.e. fifth fault), then the oldest fault (U3-04) is lost. The fifth fault now becomes the most recent fault (U3-01) and all the other faults move down one step.

Table A-5 Constants List

Digital Operator Function Display	Digital Operator Display	Constant No.	Constant Name	Setting Range	Factory Setting	Change during Operation (○=enable, X=disable)	Data Selection	Control Method (○=Setting enable, X=Setting disable)			
								V/f Control	V/f with FdG Feedback	Open Loop Vector	Flux Vector
Sequence	Reference Source	B1-01	Reference selection	0 to 3	1	X	0 : Operator 1 : Terminal 2 : Serial Cam 3 : Option PCB	○	○	○	○
	Run Source	B1-02	Operation method selection	0 to 3	1	X	0 : Operator 1 : Terminal 2 : Serial Cam 3 : Option PCB	○	○	○	○
	Stopping Method	B1-03	Stopping method	0 to 3	0	X	0 : Ramp to Stop 1 : Coast to Stop 2 : DC Inj to Stop 3 : Coast w/ Timer	○	○	○	○
	Reverse Oper	B1-04	Prohibition of reverse operation	0 to 1	0	X	0 : Reverse Enabled 1 : Reverse Disabled	○	○	○	○
Accel/Decel	Accel Time 1	C1-01	Acceleration time 1	0 to 6000.0sec	10.0sec	○		○	○	○	○
	Decel Time 1	C1-02	Deceleration time 1	0 to 6000.0sec	10.0sec	○		○	○	○	○
	Accel Time 2	C1-03	Acceleration time 2	0 to 6000.0sec	10.0sec	○		○	○	○	○
	Decel Time 2	C1-04	Deceleration time 2	0 to 6000.0sec	10.0sec	○		○	○	○	○
Preset Reference	Reference 1	D1-01	Preset reference 1	0 to 400.00Hz	0.0Hz	○		○	○	○	○
	Reference 2	D1-02	Preset reference 2	0 to 400.00Hz	0.0Hz	○		○	○	○	○
	Reference 3	D1-03	Preset reference 3	0 to 400.00Hz	0.0Hz	○		○	○	○	○
	Reference 4	D1-04	Preset reference 4	0 to 400.00Hz	0.0Hz	○		○	○	○	○
	Jog Reference	D1-09	Jog reference	0 to 400.00Hz	6.0Hz	○		○	○	○	○



Table A-5 Constants List (Cont'd)

Digital Operator Function Display	Digital Operator Display	Constant No.	Constant Name	Setting Range	Factory Setting	Change during Operation (X=Disable)	Data Selection	V/f Control	V/with Feed-back	Open Loop Vector	Flux Vector	
	Input Voltage	E1-01	Input voltage	180 to 220V*	220 V*	X						
	Motor Selection	E1-02	Motor selection	0 to 2	0	X	0 : Std Fan Cooled 1 : Std BlowerCooled 2 : Inv BlowerCooled					
V/F Pattern	V/F Selection	E1-03	V/f pattern selection	0 to 0F	0F	X	0 : 50HZ					
							1 : 60HZ Saturation					
							2 : 50HZ Saturation					
								3 : 72HZ VT1				
								4 : 50HZ VT1				
								5 : 60HZ VT2				
								6 : 50HZ VT2				
								7 : 60HZ VT1				
								8 : 50HZ HST1				
								9 : 60HZ HST2				
							A : 50HZ HST1					
							B : 60HZ HST2					
							C : 90HZ					
							D : 120HZ					
							E : 180HZ					
							F : User Defined V/F					
	Max Frequency	E1-04	Max. frequency	50.0 to 400.0Hz	60.0Hz	X						
	Max Voltage	E1-05	Max. voltage	0.0 to 255.0V*	200.0V*	X						
	Base Frequency	E1-06	Base frequency	0.0 to 400.0Hz	60.0Hz	X						
	Mid Frequency A	E1-07	Mid. output frequency	0.0 to 400.0Hz	3.0Hz	X						
	Mid Voltage A	E1-08	Mid. output voltage	0.0 to 255.0V*	10.0V*	X						
	Min Frequency	E1-09	Min. output frequency	0.0 to 400.0Hz	0.5Hz	X						
	Min Voltage	E1-10	Min. output voltage	0.0 to 255.0V*	1.7V*	X						
Motor Setup	Motor Rated FLA	E2-01	Motor rated current	0.00 to 1500A	†	X						
	Motor Rated Slip	E2-02	Motor rated slip	0.00 to 20.00Hz	†	X						
	No-Load Current	E2-03	Motor no-load current	0.00 to 1500A		X						
	Number of Poles	E2-04	Number of motor poles	2 to 48	4	X						

\* For 440V class, the value is twice as that of 220V class.

† Depends on model type.

Table A-5 Constants List (Cont'd)

Digital Operator Function Display	Digital Operator Display	Constant No.	Constant Name	Setting Range	Factory Setting	Change during Operation (○=Enable, X=Disable)	Data Selection	Control Method (○=Setting enable, X=Setting disable)			
								V/f Control	V/f with PG Feed-back	Open Loop Vector	Flux Vector
PG Option Setup	PG Pulse/Rev	F1-01	PG constant	0 to 60000	600	X		X	○	X	○
	PG Fdbk Loss Sel	F1-02	Operation selection at PG open circuit	0 to 3	1	X		X	○	X	○
	PG Overspeed Sel	F1-03	Operation selection at overspeed	0 to 3	1	X		X	○	X	○
	PG Deviation Sel	F1-04	Operation selection at deviation	0 to 3	1	X		X	○	X	○
	PG Rotation Sel	F1-05	PG rotation	0/1	0	X		X	○	X	○
	PG Output Ration	F1-06	PG division rate	1 to 132	1	X		X	○	X	○
	PG Ramp PI/I Sel	F1-07	Integral value during accel/decel enable/disable	0/1	0	X		X	○	X	○
AI-14 Setup	AI-14 Input Sel	F2-01	B1-polar or uni-polar input selection	0/1	0	X		○	○	○	○
DI-08,16 Setup	DI Input	F3-01	Digital input option	0 to 8	0	X		○	○	○	○
AO-08,12 Setup	AO Ch1 Select	F4-01	CH1 monitor selection*	1 to 31	2	X		○	○	○	○
	AO Ch1 Gain	F4-02	CH1 gain	0 to 2,50	1,00	○		○	○	○	○
	AO Ch2 Select	F4-03	CH2 monitor selection*	1 to 31	3	X		○	○	○	○
	AO Ch2 Gain	F4-04	CH2 gain	0 to 2,50	1,00	○		○	○	○	○
DO-02 Setup	DO-02 Ch1 Select	F5-01	CH1 output selection	0 to FF	0	X		○	○	○	○
	DO-02 Ch2 Select	F5-02	CH2 output selection	0 to FF	1	X		○	○	○	○
DO-08 Setup	DO-08 Selection	F6-01	Output mode selection	0 to 2	0	X		○	○	○	○
PO-36F Setup	PO-36F Selection	F7-01	Frequency multiple selection	0 to 4	0	X		○	○	○	○

\* CH1, CH2 = Channel 1, Channel 2

Table A-5 Constants List (Cont'd)

Digital Operator Function Display	Digital Operator Display	Coin-start NO.	Constant Name	Setting Range	Factory Setting	Change Operation (C=Enable, X=Disable)	Data Selection	Control Method (O=Setting enable, X=Setting disable)		
								V/f Control	V/f with PG Feed-back	Open Loop Vector
Digital Inputs	Terminal 3 Sel	H1-01	Multi-function input (terminal 3)	00 to FF	24	X	(External fault)	O	O	O
	Terminal 4 Sel	H1-02	Multi-function input (terminal 4)	00 to FF	14	X	(Fault reset)	O	O	O
	Terminal 5 Sel	H1-03	Multi-function input (terminal 5)	00 to FF	3	X	(Multi-step speed ref. 1)	O	O	O
	Terminal 6 Sel	H1-04	Multi-function input (terminal 6)	00 to FF	4	X	(Multi-step speed ref. 2)	O	O	O
	Terminal 7 Sel	H1-05	Multi-function input (terminal 7)	00 to FF	6	X	(Jog reference)	O	O	O
	Terminal 8 Sel	H1-06	Multi-function input (terminal 8)	00 to FF	8	X	(External baseblock)	O	O	O
	Terminal 9 Sel	H2-01	Multi-function output (terminal 9-10)	00 to FF	0	X	(During running)	O	O	O
	Terminal 25 Sel	H2-02	Multi-function output (terminal 25)	00 to FF	1	X	(Zero speed)	O	O	O
Digital Outputs	Terminal 26 Sel	H2-03	Multi-function output (terminal 26)	00 to FF	2	X	(Frequency agree)	O	O	O
	Term 13 Signal	H3-01	Signal level selection (terminal 13)	0/1	0	X	0 : 0-10VDC 1 : -10+10VDC	O	O	O
Analog Inputs	Terminal 13 Gain	H3-02	Gain (terminal 13)	0.0 to 1000.0%	100.0%	O		O	O	O
	Terminal 13 Bias	H3-03	Bias (terminal 13)	-100.0 to 100.0%	0.0%	O		O	O	O
	Term 16 Signal	H3-04	Signal level selection (terminal 16)	0/1	0	X	0 : 0-10VDC 1 : -10+10VDC	O	O	O
	Terminal 16 Sel	H3-05	Multi-function analog input selection (terminal 16)	0 to 1F	0	X	See Table A-7.	O	O	O
	Terminal 16 Gain	H3-06	Gain (terminal 16)	0.0 to 1000.0%	100.0%	O		O	O	O
	Terminal 16 Bias	H3-07	Bias (terminal 16)	-100.0 to 100.0%	0.0%	O		O	O	O
	Terminal 21 Sel	H4-01	Monitor selection (terminal 21)	1 to 31	2	X	See Table A-6.	O	O	O
	Terminal 21 Gain	H4-02	Gain (terminal 21)	0 to 2.50	1.00	O		O	O	O
Analog Outputs	Terminal 21 Bias	H4-03	Bias (terminal 21)	-10 to +10.0%	0.0%	O		O	O	O
	Terminal 23 Sel	H4-04	Monitor selection (terminal 23)	1 to 31	3	X	See Table A-6.	O	O	O
	Terminal 23 Gain	H4-05	Gain (terminal 23)	0 to 2.50	1.00	O		O	O	O
	Terminal 23 Bias	H4-06	Bias (terminal 23)	-10 to +10.0%	0.0%	O		O	O	O
	Slip Comp Gain	C3-01	Slip compensation gain	-2.5 to +2.5	0.0	O		O	O	O
	Torque Comp Gain	C4-01	Torque compensation gain	0 to 2.50	1.00	O		O	O	O
	ASR P Gain 1	C5-01	ASR proportional gain 1	0 to 300.00	0.00	O		X	O	O
	ASR I Time 1	C5-02	ASR integral time 1	0 to 10.000sec	0.00sec	O		X	O	O
ASR Tuning*	ASR P Gain 2	C5-03	ASR proportional gain 2	0 to 300.00	0.00	O		X	O	O
	ASR I Time 2	C5-04	ASR integral time 2	0 to 10.000sec	0.00sec	O		X	O	O

\*ASR = Automatic Speed Regulator

Table A-5 Constants List (Cont'd)

Digital Operator Function Display	Digital Operator Display	Constant No.	Constant Name	Setting Range	Factory Setting	Change during Operation (○=Enable, X=Disable)	Data Selection	Control Method (○=Setting enable, X=Setting disable)		
								V/f Control	V/f with PG Feed-back	Open Loop Vector
Carrier Freq	CarrierFreq Max	C6-01	Carrier frequency upper limit	0.4 to 15.0kHz	15.0kHz z	X		○	○	○
	DCInj Start Freq	B2-01	Zero speed level (DC braking freq.)	0.0 to 20.0Hz	0.5	X		○	○	○
DC Braking*	DCInj Current	B2-02	DC braking current	0 to 100%	50%	X		○	○	○
	DCInj Time@Start	B2-03	DC braking time at start	0.00 to 10.00sec	0.00sec	X		○	○	○
	DCInj Time@Stop	B2-04	DC braking time at stop	0.00 to 10.00sec	0.50sec	X		○	○	○
	Ref Upper Limit	D2-01	Reference upper limit	0.0 to 100.0%	100.0%	X		○	○	○
Reference Limit	Ref Lower Limit	D2-02	Reference lower limit	0.0 to 100.0%	0.0%	X		○	○	○
	Jump Freq 1	D3-01	Setting jump frequency 1	0.0 to 400.0Hz	0.0Hz	X		○	○	○
Jump frequencies	Jump Freq 2	D3-02	Setting jump frequency 2	0.0 to 400.0Hz	0.0Hz	X		○	○	○
	Jump Freq 3	D3-03	Setting jump frequency 3	0.0 to 400.0Hz	0.0Hz	X		○	○	○
	Jump Bandwidth	D3-04	Setting jump frequency range	0.0 to 20.0Hz	1.0Hz	X		○	○	○
Motor Overload	MOL Fault Select †	L1-01	Motor protection selection	0/1	1	X	0 : Disabled 1 : Coast to Stop	○	○	○
	MOL Time Const	L1-02	Motor protection time constant	1.0 to 20.0min	8.0	X		○	○	○
PwrLoss Ridethru	PwrL Selection	L2-01	Momentary power loss detection	0 to 2	0	X	0 : Disabled 1 : PwrL RideThru 2 : CPU Power Active	○	○	○
	PwrL Ridethru t	L2-02	Momentary power loss time	0.0 to 2.0sec	X	X		○	○	○
	PwrL Baseblock t	L2-03	Min. baseblock time	0.0 to 3.0sec	X	X		○	○	○
	StallP Accel Sel	L3-01	Stall prevention selection during accel	0 to 2	1	X	0 : Disabled 1 : General Purpose 2 : Intelligent	○	○	X
Stall Prevention	StallP Accel Lvl	L3-02	Stall prevention level during accel	0 to 200%	170%	X		○	○	X
	StallP Decel Sel	L3-04	Stall prevention selection during decel	0 to 2	1	X	0 : Disabled 1 : General Purpose 2 : Intelligent	○	○	○
	StallP Run Sel	L3-05	Stall prevention selection during running	0 to 2	1	X	0 : Disabled 1 : Decel Time 1 2 : Decel Time 2	○	○	X
	StallP Accel Lvl	L3-06	Stall prevention level during running	0 to 200%	160.0%	X		○	○	X
Ref Detection	Spd Agree Level	L4-01	Speed agree detection level	0.0 to 400.0Hz	0.0Hz	X		○	○	○
	Spd Agree Width	L4-02	Speed agree detection width	0.0 to 20.0Hz	2.0Hz	X		○	○	○

\* DC = Direct Current

† MOL = Motor Overload

Table A-5 Constants List (Cont'd)

Digital Operator Function Display	Digital Operator Display	Constant No.	Constant Name	Setting Range	Factory Setting	Change during Operation (O=Enable, X=Disable)	Data Selection	Control Method (O=Setting enable, X=Setting disable)			
								V/f Control	V/f with F/G Feedback	Open Loop Vector	Flux Vector
Fault Restart	Num of Restarts	L5-01	No. of auto restart attempts	0 to 10	0	X	0 : No Flt Relay 1 : Flt Relay Active	O	O	O	O
	Restart Sel	L5-02	Auto restart operation selection	0/1	0	X	0 : Disabled 1 : @ Spd/Agree-Alm 2 : At RUN-Alarm 3 : @ Spd/Agree-Fit 4 : At RUN-Fault	O	O	O	O
Torque Detection	Torq Det 1 Sel	L6-01	Torque detection selection	0 to 4	0	X		O	O	O	O
	Torq Det 1 Lvl	L6-02	Torque detection level	0 to 300%	160%	X		O	O	O	O
	Torq Det 1 Time	L6-03	Torque detection time	0.0 to 10.0sec	0.1sec	X		O	O	O	O
	Torq Limit Fwd	L7-01	Forward torque limit	0 to 300%	200%	X		O	O	O	O
	Torq Limit Rev	L7-02	Reverse torque limit	0 to 300%	200%	X		O	O	O	O
	Torq Limit Fwd Rgn	L7-03	Forward regenerative torque limit	0 to 300%	10%	X		O	O	O	O
Torque Limit	Torq Limit Rev Rgn	L7-04	Reverse regenerative torque limit	0 to 300%	10%	X		O	O	O	O
	DB Resistor Prot †	L8-01	Protect selection for internal DB resistor	0/1	0	X	0 : Not Provided 1 : Provided	X	X	O	O
Hdwe Protection *	Monitor Select	O1-01	Monitor selection	4 to 26	6	O	See Table A-4.	O	O	O	O
	Power-On Monitor	O1-02	Monitor selection after power up	1 to 4	1	O	1 : Frequency Ref 2 : Output Freq 3 : Output Current 4 : Selected Monitor	O	O	O	O
Monitor Select	Display Scaling	O1-03	Freq. units of ref. setting and monitor	0 to 39999	0	X		O	O	O	O
	Display Units	O1-04	Freq. units of constant setting	0/1	0	X	0 : Hertz 1 : RPM	X	X	X	X
	Local/Remote Key	O2-01	REMOTE/LOCAL key enable/disable	0/1	1	X	0 : Disabled 1 : Enabled	O	O	O	O
	Oper STOP Key	O2-02	STOP key during external terminal operation (enable/disable)	0/1	1	X	0 : Disabled 1 : Enabled	O	O	O	O
Key Select	User Default	O2-03	User constant initial value	0 to 2	0	X	0 : No Change 1 : Set Default 2 : Clear All	O	O	O	O
	Inverter Model #	O2-04†	kVA selection	0 to FF	—	X		O	O	O	O

\* Hdwe = Hardware  
† DB = Dynamic Brake

Table A-6 Multi-digital Output

Set Value	Function Name	Set Value	Function Name
00	During RUN 1	10	Minor Fault
01	Zero Speed	11	Reset Cmd Active
02	Fref/Fout Agree 1	12	Timer Output
03	Fref/Set Agree 1	13	Fref/Fout Agree 2
04	Freq Detect 1	14	Fref/Set Agree 2
05	Freq Detect 2	15	Freq Detect 3
06	Inverter Ready	16	Freq Detect 4
07	DC Bus undervolt	17	Trq Det 1 N.C.
08	BaseBlk 1	18	Trq Det 2 N.O.
09	Option Reference	19	Trq Det 2 N.C.
0A	Remote Operation	1A	Reverse Dir
0B	Trq Det 1 N.O.	1B	BaseBlk 2
0C	Loss of Ref	1C	Motor 2 Selected
0D	DB Overheat	1D	Regenerating
0E	Fault	1E	Restart Enabled
0F	Not Used	1F	Overload (OL1)
—		20	OH Prealarm
		21-2F	Not Used
		30	Current / Trq LIM
		31	Speed Limit
		32	Not Used
		33	Zero Servo End
		34	During RUN 2
		35-3F	Not Used

Table A-7 Multi-analog Input

Set Value	Function Name	Set Value	Function Name
00	Aux Reference	10	Fwd Torque Limit
01	Frequency Gain	11	Rev Torque Limit
02	Frequency Bias	12	Regen Torq Limit
03	Voltage Bias	13	Torque Reference
04	Acc/Dec Change	14	Torque Comp
05	DCInj Current	15	Speed Limit
06	OverTorque Level	16-1F	Not Used
07	Stall Prev Level	—	
08	Ref Lower Limit		
09	Jump Frequency		
0A	PID Feedback		
0B-0F	Not Used		

Table A-8 Constants Array

MENU	Group	Function	Constant No.				
			Q	B	A	F	
	Operation	U   Monitor	U1 Monitor	01-14	15-19	20-29	
		U2 Fault trace	01-14				
		U3 Fault history	01-08				
	A   Initialize	A1 Initialize	00-04				
		A2 User constants			01-32		
		B   Application	B1 Sequence	01-03	04	05-07	
			B2 DC braking		01-04		05-07
			B3 Speed search			01-03	04
			B4 Delay timers			01, 02	
			B5 PID control			01-08	
			B6 Reference hold			01-04	
			B7 Droop control			01, 02	
			B8 Energy saving			01, 02	
			B9 Zero servo			01, 02	
				C   Tuning	C1 Accel/decel	01, 02	03, 04, 09
	C2 S-curve accel/decel					01-04	
	C3 Motor-slip compensation				01	02-04	04
	C4 Torque compensation				01	02	
C5 ASR tuning		01-04			05-07		
C6 Carrier frequency		01			02, 03		
C7 Hunting prevention					01	02-04	
C8 Factory tuning						01-28	
	D   Reference	D1 Preset reference	01-04, 09	05-08			
		D2 Reference limit		01, 02			
		D3 Jump frequency		01-04			
		D4 Sequence			01, 02		
		D5 Torque control			01-04		
	E   Motor	E1 V/f pattern 1	01-10		11-13		
		E2 Motor setup 1	01-04		05-09		
		E3 Motor 2 control method			01		
		E4 V/f pattern 2			01-07		
		E5 Motor setup 2			01-05		
	F   Option	F1 PG option setup	01	02-07	08-13		
		F2 AI-14 setup		01			
		F3 DI-08, 16 setup		01			
		F4 AO-08 setup		01-04			
		F5 DO-02 setup		01, 02			
		F6 DO-08 setup		01			
		F7 PO-36F setup		01			
	H   Terminal	H1 Digital inputs		01-06			
		H2 Digital outputs		01-03			
		H3 Analog inputs		01-07	08-12		
		H4 Analog outputs		01-06			
		H5 Serial communication setup			01-04		
	L   Protection	L1 Motor overload		01, 02			
		L2 Power loss ride-thru		01-03	04, 05		
		L3 Stall prevention		01, 02, 04-06	03	07, 08	
		L4 Reference detection		01, 02	03-05		
		L5 Fault restart		01, 02			
		L6 Torque detection		01-03	04-06		
		L7 Torque limit	01-04			05, 06	
		L8 Hardware protection		01	02, 03, 05, 07	04, 06, 07-13	
	O   Operator	O1 Monitor select		01-04	05		
		O2 Key select		01-04	05-08		